Business Furniture Online Ltd.
for all your office furniture needs

Impact Chair - Operating Instructions

Fitted with Synchro mechanism.
All instructions given from a seated position

Back Height Adjustment
Lift the back on it's ratchet one step at a time until comfortable. When the back reaches the top if it's travel it will drop back to the start position.

Lumbar Support
Using the hand bulb hanging under the seat to the rear of the left side, squeeze to inflate the lumbar support. Press the button to release air and deflate support.

Seat and Back Movement (Lever under seat, left side)
Push down on lever then lean back into backrest to unlock. Move back rest to desired position and raise lever to lock. Lever can be left in down position if you prefer the seat unlocked to move with you.

Standard Height Adjustable Armrests
Height of armrests can be adjusted by raising armrest on it's ratchet. When at the top of the ratchet, the armrest will fall to the bottom position again.

Seat Depth Adjustment
Push the button. Slide the seat forward or backwards then release the button to lock into position.

Gas Height Adjustment Lever
Lift lever to adjust height of chair up and down. Raise weight off chair when lifting lever.

Tension Control (Rotary Control)
Seat tension can be adjusted by twisting control to tighten or loosen tension.

(March 2011)